

**Tag Browser**

- Random
- ReadOnly
- Realistic
- Sine
  - Sine0 -79.98 Float8

**Property Editor**

Mouseover Text	
Cursor	Default
<b>Data</b>	
Value	20.309491726
Overall Low Bound	-100.0
Overall High Bound	100.0
Reverse Range?	<input type="checkbox"/> false
Data Quality	192

The meter appears in Ignition Designer has a range from -100 to 100.

**Ignition!**  
by inductive automation

**Overview**

- Overview
- User Management
- Schedule Management
- Roster Management

Current Time:  
07/04/2019 04:15 PM

**Overview**

[Open Popup](#)

After launching the above project from the ignition gateway, the range of the same meter changes from 0 to 100 (its default range)